





ACTUATED INLET (DL3127) INSTALLATION MANUAL PART #: ST76998




**DO NOT STORE IN
DIRECT SUNLIGHT**



INSTALLATION INSTRUCTIONS

- Need framed opening of 29" x 24.75"
- Install attic sleeve in framed opening
- Run bead of caulk around the top, outside edge of the inlet.
- Fasten inlet to the ceiling with 10 - #10 x 2" screws (supplied).
- Run pull line through the inlet and center winch blocks.
- With actuator in full closed position, fasten nylon pull strings close to outside edge of inlet and center winch block using plastic split bolt and nut.
- With black ball and split bolt nut, anchor lid to closed position.
- Open and shut inlet a few times. Then readjust lids as needed.



DISCLAIMER OF WARRANTIES AND LIMITATION OF REMEDIES: DOUBLE L GROUP, LLC DISCLAIMS ANY AND ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. UNDER NO CIRCUMSTANCES, SHALL DOUBLE L GROUP, LLC OR ANY OF ITS EMPLOYEES, DIRECTORS, OFFICERS, OR AGENTS, BE LIABLE FOR ANY DIRECT OR INDIRECT LOSSES OR DAMAGES ARISING FROM OR RELATED TO ANY PRODUCT PURCHASED, WHETHER SUCH DAMAGES ARE GENERAL, SPECIAL, CONSEQUENTIAL, INCIDENTAL, ECONOMIC, EXEMPLARY OR OTHERWISE (INCLUDING BUT NOT LIMITED TO DAMAGE OR INJURIES TO PERSONS, PROPERTY, OR ANIMALS). WHETHER IN TORT OR CONTRACT, EVEN IF AN AUTHORIZED REPRESENTATIVE OF DOUBLE L GROUP, LLC HAS BEEN ADVISED OF OR SHOULD HAVE KNOWN OF THE POSSIBILITY OF SUCH DAMAGES.